



DISC HARROW

DHP8/10/12

Published 03/16

P/N 00789085P

PART'S MANUAL



An Operator's Manual was shipped with the equipment in the Manual Canister. This Operator's Manual is an integral part of the safe operation of this machine and must be maintained with the unit at all times. **READ, UNDERSTAND, and FOLLOW** the Safety and Operation Instructions contained in this manual before operating the equipment. If the Operator's Manual is not with the equipment, contact your dealer or Servis-Rhino (800-446-5158) to obtain a Free copy before operating the equipment.



RHINO®

1020 S. Sangamon Ave.
Gibson City, IL 60936
800-446-5158

Email: parts@servis-rhino.com

ATENCIÓN!

Si No Lee Ingles, Pida Ayuda a Alguien
Que Si Lo Lea Para Que le Traduzca las
Medidas de Seguridad.

LEA EL INSTRUCTIVO



**A MEMBER OF THE
ALAMO GROUP**
ALWAYS ON THE CUTTING EDGE™

© 2015 Alamo Group Inc.

TO THE OWNER/OPERATOR/DEALER

All implements with moving parts are potentially hazardous. There is no substitute for a cautious, safe-minded operator who recognizes the potential hazards and follows reasonable safety practices. The manufacturer has designed this implement to be used with all its safety equipment properly attached to minimize the chance of accidents.


BEFORE YOU START!! Read the safety messages on the implement and shown in your manual.
Observe the rules of safety and common sense!



DANGER

FAILING TO FOLLOW SAFETY MESSAGES AND OPERATING INSTRUCTIONS CAN CAUSE SERIOUS BODILY INJURY OR EVEN DEATH TO OPERATOR AND OTHERS IN THE AREA.

1.



2. NO RIDERS, NO CHILDREN OPERATORS



3. USE SAFETY SHOES, HARD HAT, SAFETY GLASSES, SEAT BELTS, & ROPS



4. BLOCK UP SECURELY BEFORE WORKING UNDER.



1. Study and understand Operator's Manuals, Safety Signs, and Instructional Decals for tractor & flail mower to prevent misuse, abuse, & accidents. Practice before operating mower in a confined area or near passersby.

- Learn how to stop engine suddenly in an emergency. Be alert for passersby and especially children.
2. Allow no children on or near implement or tractor. Allow no riders on tractor or implement. Falling off can cause serious injury or death from being run over by tractor or mower or contact with Flail Mower Blades.
3. Operate only with tractor having Roll-Over Protective Structure (ROPS) and with seatbelt fastened securely and snugly to prevent injury and possible death from falling off or tractor overturn. Personal Protective Equipment such as Hard Hat, Safety Glasses, Safety Shoes, and Ear Plugs are recommended.
4. Block up or support raised machine and all lifted components securely before putting hands or feet under or working underneath any lifted component to prevent crushing injury or death from sudden dropping or inadvertent operation of controls. Make certain that area is clear before lowering or folding.
5. Before transporting, put Lift Lever in detent or full-lift position. Install Transport Safety Devices securely on folding implements. Slow down when turning and on hillsides.
- Install **Restrictor in folding circuit to slow down lowering and unfolding if action is faster than is desirable.
6. Make certain that SMV sign, Warning Lights, and Reflectors are clearly visible. Follow local traffic codes.
7. Never operate with Flail Mower or Folding Section raised if passersby, bystanders or traffic are in the area to reduce possibility of injury or death from objects thrown by Blades under Shields or implement structure.
8. Before dismounting, secure flail mower in transport position or lower to ground.
- Put tractor in park or set brake, disengage PTO, stop engine, remove key, and wait until noise of rotation has ceased to prevent entanglement in rotating parts which may cause injury or death.
 - Never mount or dismount a moving vehicle. Crushing from runover may cause injury or death.

5. TRANSPORT SAFELY, LOCK UP.



6. USE SMV, LIGHTS, & REFLECTORS.



7. DO NOT OPERATE WITH MOWER OR WING RAISED.



8. DO NOT MOUNT OR DISMOUNT WHILE MOVING.



002369

WARRANTY INFORMATION:

Read and understand the complete Warranty Statement found in this Manual. Fill out the Warranty Registration Form in full and return it within 30 Days. Make certain the Serial Number of the Machine is recorded on the Warranty Card and on the Warranty Form that you retain. The use of "will-fit" parts will void your warranty and can cause catastrophic failure with possible injury or death.

PARTS SECTION

PARTS ORDERING GUIDE

The following instructions are offered to help eliminate needless delay and error in processing purchase orders for the equipment in this section.

1. The Parts Section is prepared in logical sequence and grouping of parts that belong to the basic machine featured in this manual. Part Numbers and Descriptions are given to help locate the parts and quantities required.
2. The Purchase Order must include the name and address of the person or organization ordering the parts, who should be charged, and if possible, the serial number of the machine for which the parts are ordered.
3. The Purchase Order must clearly list the quantity of each part, the complete and correct part number (be sure to include all periods), and the basic name of the part.
4. The Manufacturer reserves the right to substitute parts where applicable.
5. Some parts are unlisted items which are special production items not normally stocked and are subject to special handling. Request a quotation for such parts before sending a Purchase Order.
6. The Manufacturer reserves the right to change prices without prior notice.

NOTE: Please refer to The Safety Section in the front of this Manual for the proper Part Number when ordering Replacement Safety Decals.



For maximum safety and to guarantee optimum product reliability, always use genuine Servis-Rhino Parts. The use of inferior replacement parts may cause premature or catastrophic failure which could result in serious injury or death. Direct any questions regarding parts to:



RHINO®
1020 S. Sangamon Ave.
Gibson City, IL 60936
800-446-5158
Email: parts@servis-rhino.com


TABLE OF CONTENTS

PULL DISC HARROWS

DHP8, DHP10, DHP12


COMPONENT	LOCATION
Frame & Related Parts	29-1-1
Tongue & Related Parts	29-1-2
Axle & Related Parts.....	29-1-4
Disc Gangs & Related Parts	29-1-5
Scrapers & Related Parts	29-1-6
Hydraulic Components & Related Parts	29-1-7
Decals - Safety & Marking	29-1-8
SMV Placard	29-1-9

PULL DISC HARROW DHP8, DHP10, DHP12 FRAMES AND RELATED PARTS



Ref. No.	Part No.	Description	Qty. Req'd.
1	50072260	Frame Weldment DHP8	1
	50072292	Frame Weldment DHP10 & DHP12	1
2	50072271	Handle, Adjusting	1
3	50072270	Adjusting Plate, Angle	2
4	50072263	Adjusting Weldment, Angle	2
5	50072264	Adjusting Plate, Bottom	2
6	50072276	Bushing	4
7	45321BH	Locknut 1-3/4" Nylock	4
8	44064BH	Capscrew 3/4" x 5' Gr.5	4
9	99334	Cylinder Pin 1" x 3-1/2"	1
10	50005860	Pin .148" x 3/4"	5


PULL DISC HARROW **DHP8, DHP10, DHP12** **TONGUE AND RELATED PARTS**



PULL DISC HARROW DHP8, DHP10, DHP12 TONGUE AND RELATED PARTS


Ref. No.	Part No.	Description	Qty. Req'd.
1	50072283	Tongue Weldment	1
2	50072282	Pull Hitch	1
3	91091	Safety Chain	1
4	50072285	Jack Assembly	1
5	50072277	Capscrew 1-1/4" x 6-1/2" Gr.5	1
6	20305	Hex Nut 1-1/4"	1
7	50072279	Jam Nut 1-1/4"	1
8	20570	Flatwasher 1-1/4"	4
9	50072280	Capscrew " x 6-1/2" Gr.5	1
10	50072278	Hex Locknut 1" Nylock	2
11	20860	Capscrew 1" x 7-1/2" Gr.5	1
12	50072281	Safety Chain Washer	1
13	50072284	Hose Holder	1
14	20054	Capscrew 1/2" x 1" Gr.5	1
15	15829	Flatwasher 1/2" SAE	2
16	50072274	Pin 7/8" x 6"	1
17	21020820	Cotter Pin 1/8" x 2"	4
18	50072257	Capscrew 7/8" x 4" Gr.5	3
19	50022258	Hex Locknut 7/8" Nylock	3
20	50072262	Pivot Assembly	1
21	50072255	Grease Fitting	3
22	50072273	Pin 7/8" x 7-1/2"	1
23	50072269	Retainer Plate, Spring Cap	2
24	20118	Capscrew 5/8" x 7" Gr.5	1
25	45020BH	Hex Locknut 5/8" Nylock	1
26	50072286	Threaded Rod Weldment	1
27	50072266	Spring, Upper	1
28	50072294	Spring Cup Weldment	1
29	50072268	Spring, Lower	1
30	15913	Flatwasher 1-1/8"	1
31	20304	Hex Nut, Heavy Duty 1-1/8"	2
32	50072287	Tube Weldment	1
33	1162424	Capscrew 3/4" x 2-1/2" Gr.5	1
34	45321BH	Locknut 3/4" Nylock	1

PULL DISC HARROW DHP8, DHP10, DHP12 AXLE AND RELATED PARTS



Ref. No.	Part No.	Description	Qty. Req'd.
1	50072290	Wheel and Tire Assy.	2
2	50072288	Hub Assy. Complete	2
3	50072291	Lug Nut 1/2"	10
4	50072289	Axle Spindle	2
5	50072256	Capscrew 1/2" 1/2" x 3-1/4" Gr.5	4
6	44539BH	Locknut 1/2" Nylock	4
7	20110BH	Capscrew 1/2" x 2" Gr.5	12
8	50072265	Axle Clamp	3
9	50072261	Axle Weldment for DHP8	1
	50072293	Axle Weldment for DHP10 and DHP12	1


PULL DISC HARROW DHP8, DHP10, DHP12 DISC ASSEMBLES and RELATED PARTS



Ref. No.	Part No.	Description	Qty. Req'd.	Ref. No.	Part No.	Description	Qty. Req'd.
1	50073400	Disc Blade 20" Scalloped	a/r	12	44539BH	Locknut 1/2" Nylock	1
	50073401	Disc Blade 22" Scalloped	a/r	13	50072299	Gang Hanger	a/r
2	50072296	Disc Blade 18" Scalloped	a/r	14	50072298	U-Bolt 5/8" x 5-1/2"	1
	50073399	Disc Blade 16" Scalloped	a/r	15	50069601	Axle Bolt w/Nut 42"	1
3	50069595	End Washer	1		50069603	Axle Bolt w/Nut 40-1/4"	1
4	50069593	Spacer 4-1/2" (7-1/2 & 9" Sp.)	a/r		50072295	Axle Bolt w/Nut 57-1/2"	1
5	50069597	Bearing, Sealed 1-1/8"	a/r		50073889	Axle Bolt w/Nut 58-1/2"	1
6	50069594	Spacer 3-1/4" (9" Spacing)	a/r		50072303	Axle Bolt w/Nut 65"	1
	50069602	Spacer 1-3/4" (7-1/2" Spacing)	a/r		50073890	Axle Bolt w/Nut 67-1/2"	1
7	50069592	Spacer (7-1/2" Spacing)	a/r	16	45020BH	Hex Locknut 5/8"	1
	50069599	Spacer (9" Spacing)	a/r	17	20748	Flatwasher 5/8" Sae	1
8	50069598	End Washer	1	18	50072301	Gang Tube 45"	1
9	-----	Axle Nut	1		50072297	Gang Tube 60"	1
10	50072300	Jamb Nut 1-1/8 Nylock	1		50072302	Gang Tube 68"	1
11	44134BH	Carriage Bolt 1/2" x 1-3/4" Gr5	1				


a/r = as required

PULL DISC HARROW DHP8, DHP10, DHP12 SCRAPERS and RELATED PARTS




Ref. No.	Part No.	Description	Qty. Req'd.
1	50071191	Scraper L.H. Front & R.H. Rear	a/r
2	50071192	Scraper R.H. Front & L.H. Rear	a/r
3	50071188	"U" Bolt 3/8" x 1-5/8"	a/r
4	44624BH	Hex Locknut 3/8" Nylock	a/r
5	50072319	Scraper Attach Plate	a/r
6	50072321	Scraper Mount Tube 1-1/2" Sq. x 41-1/2" DHP8	4
	50072320	Scraper Mount Tube 1-1/2" Sq. x 56-1/2" DHP10	4
	50072322	Scraper Mount Tube 1-1/2" Sq. x 64-1/2" DHP12	4

**PULL DISC HARROW
DHP8, DHP10, DHP12
HYDRAULIC COMPONENTS and RELATED PARTS**




Ref. No.	Part No.	Description	Qty. Req'd.
1	50047475	Hyd. Cyl.(Bailey) 3-1/2" Bore x 8" Stroke	1
	50017623	Seal Repair Kit for cylinder	1
2	50072349	Hyd. Hose 1/4" x 150"	2
3	50072348	Hyd. Fitting 90	2
4	99334	Cylinder Pin 1" x 3-1/2"	2
5	50005860	Hair Pin .148" x 3"	2

PULL DISC HARROW DHP8, DHP10, DHP12 DECALS - Safety and Marking



Ref. No.	Part No.	Description	Qty. Req'd.
1	50072042	Model Decal DHP8 (Shown)	1
	50072040	Model Decal DHP10	1
	50072053	Model Decal DHP12	1
2	50057047	Caution Decal	1
3	90960BH	Warning Decal	1
4	50031212	Amber Reflector	2
5	50031213	Red Reflector	2
6	54288	Rhino Decal	3
7	00725746	Peligro Decal	1
8	N/A	Serial No. Decal	1

PULL DISC HARROW **DHP8, DHP10, DHP12** **SMV PLACARD**



Ref. No.	Part No.	Description	Qty. Req'd.
1	94359	SMV Placard	1
2	2438621	Mount Bracket	1
3	20009	Capscrew 1/4" x 1/2"	2
4	45153	Locknut 1/4"	2
5	5161012	Carriage Bolt 5/16" x 1-1/4"	2
6	45155BH	Locknut 5/16"	2

SERVIS-RHINO

LIMITED WARRANTY

1. LIMITED WARRANTIES

- 1.01. Servis-Rhino warrants for one year from the purchase date to the original non-commercial, governmental, or municipal purchaser ("Purchaser") and warrants for six months to the original commercial or industrial purchaser ("Purchaser") that the goods purchased are free from defects in material or workmanship.
- 1.02. Manufacturer will replace for the Purchaser any part or parts found, upon examination at one of its factories, to be defective under normal use and service due to defects in material or workmanship.
- 1.03. This limited warranty does not apply to any part of the goods which has been subjected to improper or abnormal use, negligence, alteration, modification, or accident, damaged due to lack of maintenance or use of wrong fuel, oil, or lubricants, or which has served its normal life. This limited warranty does not apply to any part of any internal combustion engine, or expendable items such as blades, shields, guards, or pneumatic tires except as specifically found in your Operator's Manual.
- 1.04. Except as provided herein, no employee, agent, Dealer, or other person is authorized to give any warranties of any nature on behalf of Manufacturer.

2. REMEDIES AND PROCEDURES.

- 2.01. This limited warranty is not effective unless the Purchaser returns the Registration and Warranty Form to Manufacturer within 30 days of purchase.
- 2.02. Purchaser claims must be made in writing to the Authorized Dealer ("Dealer") from whom Purchaser purchased the goods or an approved Authorized Dealer ("Dealer") within 30 days after Purchaser learns of the facts on which the claim is based.
- 2.03. Purchaser is responsible for returning the goods in question to the Dealer.
- 2.04. If after examining the goods and/or parts in question, Manufacturer finds them to be defective under normal use and service due to defects in material or workmanship, Manufacturer will:
 - (a) Repair or replace the defective goods or part(s) or
 - (b) Reimburse Purchaser for the cost of the part(s) and reasonable labor charges (as determined by Manufacturer) if Purchaser paid for the repair and/or replacement prior to the final determination of applicability of the warranty by Manufacturer.The choice of remedy shall belong to Manufacturer.
- 2.05. Purchaser is responsible for any labor charges exceeding a reasonable amount as determined by Manufacturer and for returning the goods to the Dealer, whether or not the claim is approved. Purchaser is responsible for the transportation cost for the goods or part(s) from the Dealer to the designated factory.

3. LIMITATION OF LIABILITY.

- 3.01. MANUFACTURER DISCLAIMS ANY EXPRESS (EXCEPT AS SET FORTH HEREIN) AND IMPLIED WARRANTIES WITH RESPECT TO THE GOODS INCLUDING, BUT NOT LIMITED TO, MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.
- 3.02. MANUFACTURER MAKES NO WARRANTY AS TO THE DESIGN, CAPABILITY, CAPACITY, OR SUITABILITY FOR USE OF THE GOODS.
- 3.03. EXCEPT AS PROVIDED HEREIN, MANUFACTURER SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO PURCHASER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS, OR DAMAGE CAUSED OR ALLEGED TO BE CAUSED DIRECTLY OR INDIRECTLY BY THE GOODS INCLUDING, BUT NOT LIMITED TO, ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES RESULTING FROM THE USE OR OPERATION OF THE GOODS OR ANY BREACH OF THIS WARRANTY. NOTWITHSTANDING THE ABOVE LIMITATIONS AND WARRANTIES, MANUFACTURER'S LIABILITY HEREUNDER FOR DAMAGES INCURRED BY PURCHASER OR OTHERS SHALL NOT EXCEED THE PRICE OF THE GOODS.
- 3.04. NO ACTION ARISING OUT OF ANY CLAIMED BREACH OF THIS WARRANTY OR TRANSACTIONS UNDER THIS WARRANTY MAY BE BROUGHT MORE THAN TWO (2) YEARS AFTER THE CAUSE OF ACTION HAS OCCURRED.

4. MISCELLANEOUS.

- 4.01. Proper Venue for any lawsuits arising from or related to this limited warranty shall be only in Guadalupe County, Texas.
- 4.02. Manufacturer may waive compliance with any of the terms of this limited warranty, but no waiver of any terms shall be deemed to be a waiver of any other term.
- 4.03. If any provision of this limited warranty shall violate any applicable law and is held to be unenforceable, then the invalidity of such provision shall not invalidate any other provisions herein.
- 4.04. Applicable law may provide rights and benefits to purchaser in addition to those provided herein.

KEEP FOR YOUR RECORDS

ATTENTION: Purchaser should fill in the blanks below for his reference when buying repair parts and/or for proper machine identification when applying for warranty.

Servis-Rhino Implement Model _____ Serial Number _____

Date Purchased _____ Dealer _____

ATTENTION:
READ YOUR OPERATOR'S MANUAL

RHINO®
1020 S. Sangamon Ave.
Gibson City, IL 60936
800-446-5158
Email: parts@servis-rhino.com





TO THE OWNER/OPERATOR/DEALER

To keep your implement running efficiently and safely, read your manual thoroughly and follow these directions and the Safety Messages in this Manual. The Table of Contents clearly identifies each section where you can easily find the information you need.

The OCCUPATIONAL SAFETY AND HEALTH ACT (1928.51 Subpart C) makes these minimum safety requirements of tractor operators:

REQUIRED OF THE OWNER:

1. Provide a Roll-Over-Protective Structure that meets the requirements of this Standard; and
2. Provide Seatbelts that meet the requirements of this paragraph of this Standard and SAE J4C; and
3. Ensure that each employee uses such Seatbelt while the tractor is moving; and
4. Ensure that each employee tightens the Seatbelt sufficiently to confine the employee to the protected area provided by the ROPS.

REQUIRED OF THE OPERATOR

1. Securely fasten seatbelt if the tractor has a ROPS.
2. Where possible, avoid operating the tractor near ditches, embankments, and holes.
3. Reduce speed when turning, crossing slopes, and on rough, slick, or muddy surfaces.
4. Stay off slopes too steep for safe operation.
5. Watch where you are going - especially at row ends, on roads, and around trees.
6. Do not permit others to ride.
7. Operate the tractor smoothly - no jerky turns, starts, or stops.
8. Hitch only to the drawbar and hitch points recommended by the tractor manufacturer.
9. When the tractor is stopped, set brakes securely and use park lock, if available.



Keep children away from danger all day, every day...



Equip tractors with rollover protection (ROPS) and keep all machinery guards in place...



Please work, drive, play and live each day with care and concern for your safety and that of your family and fellow citizens.

